

Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### L50 Overview

To get started, please review the following components:

- 1. Lifter arm
- 2. Hookswitch motor
- 3. Hookswitch plunger
- 4. External ring detector jack
- 5. Alert ON/OFF button
- 6. Ring sensor adjustment control
- 7. Status indicator
- 8. Lifter control cable



1 of 3 next »

Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### L50 Overview

To get started, please review the following components:

- 9. Lifter pad
- 10. Lifter arm height control
- 11. Internal ring detector
- 12. Adhesive tapes

« back 2 of 3 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### L50 Overview

To get started, please review the following components:

- 13. External ring detector
- 14. Telephone line cord
- 15. Lifter pad extender
- 16. Anti-slip pad

« back 3 of 3



Online Set-Up Guide

Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

Connecting the L50 to the V100 wireless headset system

Remove the panel from bottom of the V100 base station.

Note: The V100 should be set up before attaching the L50. See V100 Wireless Headset System user guide for instructions.

1 of 3 next »



Online Set-Up Guide

Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

Connecting the L50 to the V100 wireless headset system

Plug L50 lifter control cable into the LIFTER jack (dark blue dot).

« back 2 of 3 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

Connecting the L50 to the V100 wireless headset system

Slide panel back onto base station.

« back 3 of 3



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Remove telephone handset from the telephone cradle.

1 of 13 next »



Online Set-Up Guide

VXi

Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Make sure cradle surface is clean and dry.

« back 2 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Position L50 so the hookswitch plunger depresses the telephone hookswitch when lowered.

« back 3 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

If necessary, slide the hookswitch motor up or down to align the plunger with the telephone hookswitch.

« back 4 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Remove the adhesive tape and adhere the L50 to the telephone cradle.

Important: Adhesive affixes securely. Do not attach the L50 until you are certain that it is positioned correctly.

« back 5 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Remove the adhesive tape and adhere the L50 to the telephone cradle.

Important: Adhesive affixes securely. Do not attach the L50 until you are certain that it is positioned correctly.

« back 5 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Place the telephone handset on the lifter pad.

« back 6 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

For additional handset stability, attach the lifter pad extender into the two slots on the lifter pad.

« back 7 of 13 next »



Online Set-Up Guide

VXI

Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

To prevent the handset from slipping, remove the adhesive tape from the anti-slip pad and attach to the lifter pad.

« back 8 of 13 next »



Online Set-Up Guide

Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Set the lifter arm height control to the highest position. Replace handset.

« back 9 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Press the V100 ON/OFF button.

« back 10 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

The L50 hookswitch plunger will automatically retract. Adjust the lifter arm height control until the plunger lifts completely off the telephone hookswitch.

« back 11 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

If the telephone's speaker is not located under the handset, plug the external ring detector into the RING DETECT jack.

« back 12 of 13 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Set-up

Remove the adhesive tape and attach near the center of the telephone's speaker.

Note: The L50 may not be compatible with all phone models. If you have a question about your phone, call VXi Technical Support at 800-742-8588.

« back 13 of 13





Online Set-Up Guide

Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector


Using the L50 with a speaker phone

Set-up complete

## Operation

Select LIFTER MODE on the V100 base station.

1 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Operation

Press the V100 headset ON/OFF button.

« back 2 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Operation

The L50 will automatically release the hookswitch on your telephone and you should hear a dial tone in the headset.

« back 3 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Operation

Make a call. When the call is complete, press the V100 headset ON/OFF button again.

« back 4 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Operation

The L50 will automatically depress the hookswitch on your telephone, ending the call.

« back 5 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

#### Operation

To hear the ring tone for incoming calls in the headset, make sure the STATUS light is blue. If it is red, press the ALERT ON/OFF button.

« back 6 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Operation

To answer a call, press the V100 headset ON/OFF button.

« back 7 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Operation

The L50 will automatically release the hookswitch on your telephone to answer the call.

« back 8 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Operation

When the call is complete, press the V100 headset ON/OFF button again.

« back 9 of 10 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Operation

The L50 will automatically depress the hookswitch on your telephone, ending the call.

« back 10 of 10



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

# Adjusting the internal ring detector

If you don't hear a ring tone from an incoming call in your V100 headset, be sure that the ring volume on your phone is set at a normal level. If you still do not hear a ring tone in the headset, turn the SENSOR ADJ knob clockwise to increase sensitivity and counterclockwise to decrease sensitivity.

1 of 2 next »



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

# Adjusting the internal ring detector

The SENSOR ADJ setting is correct when the blue STATUS light on the L50 flashes quickly when the telephone rings and you hear a ring tone in your headset earpiece.

« back 2 of 2



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

# Using the L50 with a speaker phone

It is recommended that you disable the ring detector when using the speaker phone with the V100. Press the ALERT ON/OFF button to disable the ring detector. The status light will turn red.

- You will no longer hear an incoming ring tone in your headset.
- The V100 headset ON/OFF button still flashes when there is an incoming call.



Online Set-Up Guide



Overview

Connecting the L50 to the V100

Set-up

Operation

Adjusting internal ring detector

Using the L50 with a speaker phone

Set-up complete

## Set-up Complete

Congratulations! You have successfully set-up your VXi L50 handset lifter with your telephone and V100.

